# EcoNet®

Amazon Alexa Quick Commands

The EcoNet® Smart Thermostat WORKS WITH alexa, so it's easier than ever to control your comfort—with just the sound of your voice. Here is a comprehensive list of EcoNet Alexa commands, examples and Alexa's responses to commands.

☼ 80

72

WORKS WITH
alexa

For more information, visit
Ruud.com/EcoNetSmartThermostat

HVAC MODE COMMANDS TO ALEXA

Supported Modes:

- Auto

- Cool

- Heat

- Off

CHANGE MODE

Commands:

"Set <Thermostat name> to <Mode>"

"Set <Thermostat name> to <Mode> mode"

Examples:

"Set Home to Heat"

"Set Home to Heat mode"

Alexa Responses:

- Success

  - "It's set to <Mode>"

- Fail (On setting non-supported mode, like Fan)

  - "I don't know how to set <Thermostat name> to that setting"

  - "That command doesn't work on Device <Thermostat name>"

- Fail (On setting mode to equipment not available)

  - "Sorry, I didn't find <Thermostat name>"

- Fail (On setting mode while device is in Away mode, following a Vacation or has a critical alarm)

  - "<Thermostat name> is in a mode that doesn't accept requests. Please change its mode in the app or on the device."

For more information, visit
Ruud.com/EcoNetSmartThermostat

QUERY MODE

Supported Modes:

- Auto
- Cool
- Heat
- Off

Commands:

"What's <Thermostat name> set to?"

"What is <Thermostat name> set to?"

Example:

"What is Home set to?"

Alexa Responses:

- Success

        Auto Mode
        - "Auto is keeping temperature between <N> to <N>"

        Heat Mode
        - "The Heat is set to <N>"

        Cool Mode
        - "The AC is set to <N>"

        Off Mode
        - "It is Off"

- Fail

        - "Sorry I don't know that one"

        - "Sorry I am not sure"

- Fail (On setting mode while device is on non-supported mode, like Fan)

        - "Hmm, <Thermostat name> is not responding"

- Fail (On setting mode to equipment not available)

        - "Sorry, I didn't find <Thermostat name>"

HVAC SETPOINT COMMANDS TO ALEXA

Changing Setpoints

When HVAC is in Cool, Heat or Auto mode, Alexa can change setpoints in two ways:

Set setpoints to N degree OR

Adjust setpoints by N degree

SET SETPOINTS TO N DEGREE

Commands:

"Set <Thermostat name> temperature to N degrees"

"Set <Thermostat name> to N degrees"

Examples:

"Set Home temperature to 72 degrees"

"Set Home to 80 degrees"

Alexa Responses:

- Success

    Cool or Heat
    - "AC or Heat is set to N"

    Auto
    - "Auto is keeping the temperature between <N> to <N>"

- Fail (On setting temperature while device is on non-supported mode)

    - "<Thermostat name> is in a mode that doesn't accept requests. Please change its mode in the app or on the device."

- Fail (On setting temperature beyond min or max threshold)

    - "I can only set the temperature between 52 to 92 degrees"

- Fail (On setting temperature to equipment that is not available)

    - "Sorry, I didn't find <Thermostat name>"

For more information, visit
Ruud.com/EcoNetSmartThermostat

- Fail (On setting temperature while device is in Away mode, following Vacation, or has a critical alarm)

  - "<Thermostat name> is in a mode that doesn't accept requests. Please change its mode in the app or on the device."

ADJUST SETPOINTS <u>BY</u> N DEGREE

Commands:

"Increase <Thermostat name> temperature by N degrees"

"Increase <Thermostat name> by N degrees"

Examples:

"Increase Home temperature by 10 degrees"

"Increase Home by 6 degrees"

"Decrease <Thermostat name> temperature by N degrees"

"Decrease <Thermostat name> by N degrees"

Examples:

"Decrease Home temperature by 6 degrees"

"Decrease Home by 10 degrees"

"Increase <Thermostat name> temperature"

"Increase <Thermostat name>"

Examples:

"Increase Home temperature"

"Increase Home"

"Decrease <Thermostat name> temperature"

"Decrease <Thermostat name>"

Examples:

"Decrease Home temperature"

"Decrease Home"

"Make <Thermostat name> warmer"

"Make <Thermostat name> cooler"

Examples:

"Make Home warmer"

"Make Home cooler"

Alexa Responses:

- Success

    Cool or Heat
    - "AC or Heat is set to <N>"

    Auto
    - "Auto is keeping the temperature between <N> and <N>"

- Fail (On setting temperature while device is on non-supported mode, like Off or Fan)

    - "<Thermostat name> is in a mode that doesn't accept request. Please change its mode in the app or on the device."

- Fail (On setting temperature beyond min or max threshold)

    - "I can only set temperature between 52 to 92 degrees"

- Fail (On setting temperature to equipment not available)

    - "Sorry, I didn't find <Thermostat name>"

- Fail (On setting temperature while device is in Away mode, following Vacation, or has a critical alarm)

    - "<Thermostat name> is in a mode that doesn't accept requests. Please change its mode in the app or on the device."

QUERY INSIDE TEMPERATURE

Supported Modes:

- Heat
- Cool
- Auto
- Off
- Fan Only
- Emergency heat

Commands:

"What is the temperature in my <Thermostat name>?"

"What's the <Thermostat name> temperature?"

"What is the <Thermostat name> temperature?"

"Get the <Thermostat name> temperature"

Examples:

"What is the temperature in my Home?"

"What's the Home temperature?"

"What is the Home temperature?"

"Get the Home temperature"

Alexa Responses:

- Success

    - "The <Thermostat name> temperature is N degrees"

- Fail (On setting temperature to equipment not available)

    - "Sorry, I didn't find <Thermostat name>"

For more information, visit
Ruud.com/EcoNetSmartThermostat